


KRACHT

D.0024860002

Operating instructions (Translation)



Gear pump KF 3-6
English

Table of content

1 General	5
1.1 About the documentation	5
1.2 Manufacturer address	5
1.3 Other applicable documents	5
1.4 Symbols.....	6
2 Safety.....	7
2.1 Intended use.....	7
2.2 Personal qualification	7
2.3 Basic safety instructions	8
2.4 Fundamental hazards	8
3 Device description.....	10
3.1 Functional principle.....	10
3.2 Variants	11
3.3 Type key.....	13
3.4 Direction of rotation and discharge	16
3.5 Types of seals	17
3.6 Fluid seal.....	20
3.7 Special numbers	20
3.8 Shaft ends	24
4 Technical data.....	26
4.1 General.....	26
4.2 Nominal sizes.....	27
4.3 Assignment of viscosity - speed.....	28
4.4 Allowable pressures	28
4.4.1 Operating pressure at suction side.....	28
4.4.2 Operating pressure at pressure side	30
4.4.3 Compressor application.....	30
4.5 Assignment of differential pressure to viscosity.....	31
4.6 Permissible temperature range	32
4.7 Material data.....	33
4.7.1 Compressor application.....	34
4.8 Weight.....	35
4.9 Dimensions.....	35
5 Transport and storage	36
5.1 General.....	36
5.2 Transport.....	36
5.3 Storage.....	36
5.4 Storage conditions	37

6	Installation	38
6.1	Safety instructions for installation	38
6.2	Noise reduction	39
6.3	Mechanical installation	40
6.3.1	Preparation.....	40
6.3.2	Gear pump with free shaft end	40
6.4	Connection lines.....	42
6.4.1	General.....	42
6.4.2	Suction line.....	42
6.4.3	Pressure pipe.....	44
6.4.4	Connection line installation.....	44
6.5	Change of the direction of rotation.....	44
6.5.1	Gear pump without noise optimisation.....	45
6.5.2	Gear pump with noise optimisation.....	46
7	Commissioning	47
7.1	Safety instructions for start-up.....	47
7.2	Preparation	47
7.3	Filling the quench chamber	48
7.4	Pressure valve setting.....	48
7.4.1	Pressure relief valve	49
7.5	Additional commissioning.....	50
8	Removal.....	51
8.1	Safety instructions for disassembly.....	51
8.2	Dismantling	52
9	Maintenance	53
9.1	Safety instructions for maintenance	53
9.2	Maintenance work	54
9.3	Maintenance instructions.....	54
9.4	Maintenance table	55
9.4.1	Maintenance table.....	55
9.4.2	Check the rate of flow.....	56
9.4.3	Check the operating pressure.....	56
9.4.4	Check the media temperature.....	56
9.4.5	Check the device temperature	56
9.4.6	Check the function of the add-on valve	56
9.4.7	Check the equipotential bonding	56
9.4.8	Check the condition of the operating fluid	56
9.4.9	Auditory check Unusual noises	56
9.4.10	Cleaning	56
9.4.11	Visual inspection for leakage	57
9.4.12	Visual check of seal fluid level	57
9.4.13	Visual check of the gearbox condition.....	57
9.4.14	Visual check of the condition of housing parts	57
9.4.15	Visual check of the condition of the plain bearings	57
9.4.16	Visual check of the condition shaft seal	57
9.4.17	Visual check of the condition of the outboard bearing	58

9.4.18	Replacing the outboard bearing	58
9.4.19	Replacing the plain bearings.....	58
9.4.20	Replacing the shaft seal	58
9.4.21	Replacing other seals	58
10	Repair	59
10.1	Safety instructions for repairs	59
10.2	General.....	60
10.3	Fault table	61

1 General

1.1 About the documentation

These operating instructions describe the installation, operation and maintenance of the following product:

Gear pump KF 3-6

These operating instructions are an integral part of the product and must be kept in the immediate vicinity of the

product and accessible to the personnel at all time.

Different versions of the product are produced. Which version is concerned is stated on the device's type plate.

If you have any questions about this operating manual, please contact the manufacturer.

1.2 Manufacturer address

KRACHT GmbH
Gewerbestraße 20
D-58791 Werdohl
Tel: +49 2392 935-0
Fax: +49 2392 935-209
Email: info@kracht.eu
Web: www.kracht.eu

1.3 Other applicable documents

In addition to these instructions, also comply with the relevant instructions of plants or plant parts available or planned on site.

1.4 Symbols



DANGER

Identification of an immediate hazard, which can lead to death or severe bodily injury if not avoided.



WARNING

Identification of a potential medium risk hazard, which can lead to death or severe bodily injury if not avoided.



CAUTION

Identification of a possible low-risk hazard that can result in minor or moderate physical injury if not avoided.

ATTENTION

Identification of notes to prevent property damage.



NOTICE

Identification of basic safety instructions. Non-compliance can lead to hazards for people and the product



TIP

Identification of special user tips and other particularly useful or important information

2 Safety

2.1 Intended use

1. The product has been designed for operation with fluids.
Dry operation is not permitted.
2. The product may only be operated when completely filled.
3. The fluid must be compatible with the materials used in the product. Chemical expertise is required for that. Be careful with ethylene oxide or other catalytically or exothermically reacting or self-decomposing substances. Please consult the manufacturer in cases of doubt.
4. The product may only be used in normal industrial atmospheres. If there are any aggressive substances in the air, always consult the manufacturer.
5. The product may only be operated in compliance with these operating instructions and the applicable documents.
Deviating operating conditions require the express approval of the manufacturer.
6. Use of the product for purposes other than those for which it is intended invalidates any warranty.

2.2 Personal qualification

The personnel charged with the assembly, operation and maintenance of the product must have the necessary qualifications.

This can be achieved through training or appropriate instruction.

The personnel must be familiar with the contents of these operating instructions.



NOTICE

Read the operating instructions in full before using the product.

2.3 Basic safety instructions



NOTICE

Basic safety instructions

Non-compliance can lead to hazards for people and the unit.

- a) Follow existing regulations for accident prevention and safety at work as well as the internal regulations of the operating company.
- b) Ensure the greatest possible cleanliness.
- c) Wear suitable personal protective equipment.
- d) Do not remove type plates or other information or make them illegible or unrecognisable.
- e) Do not make any technical modifications.
- f) Comply with maintenance intervals.
- g) Only use spare parts approved by the manufacturer.

2.4 Fundamental hazards



⚠ DANGER

Hazardous fluids

Danger to life when handling hazardous fluids

- a) Comply with the safety data sheets and regulations on handling the hazardous fluids.
- b) Collect and dispose of hazardous fluids so that no hazard is created for persons or the environment.



⚠ DANGER

Hazardous fluids

Danger to life when handling hazardous fluids.

- a) Defective components and connection lines must be replaced or fixed without delay.
- b) Use only components and connection lines approved for the expected pressure range.



⚠ DANGER

Rotating parts

Risk to life due to entanglement or winding of parts of the body, hair or clothing items.

- a) Before carrying out any work, disconnect any drives and actuators from the power supply or depressurise them.
- b) Safely prevent restarting during the work.

**⚠ DANGER****Rotating parts**

Risk to life due to entanglement or winding of parts of the body, hair or clothing items.

- a) Take measures to prevent accidental touching of rotating parts.

**⚠ WARNING****Rotating parts**

Risk of injury caused by ejected parts

- a) Enclose rotating parts so that in the event of fracture or malfunction, there is no risk caused by ejected parts.

**⚠ WARNING****Failure of pressure bearing parts due to overload**

Risk of injury from flying parts.

Risk of injury due to splashing fluids.

- a) Before carrying out any work, depressurise the product and all connection pipes.
- b) Securely prevent the pressure from being restored during work.

**⚠ WARNING****Failure of pressure bearing parts due to overload**

Risk of injury from flying parts.

Risk of injury due to splashing fluids.

- a) Use only connections and lines approved for the expected pressure range.
- b) Securely prevent the permissible pressures from being exceeded, e.g. by using pressure relief valves or bursting discs.
- c) Pipelines must be designed in such a way that no tension e.g. caused by changes in length due to fluctuations in temperature can be transferred to the product.

**⚠ WARNING****Failure of pressure bearing parts due to overload**

Risk of injury caused by flying parts.


Risk of injury caused by splashing fluids.

- a) Do not operate the product with shut-off devices closed.
- b) Do not operate the production in the wrong rotational direction.

3 Device description

3.1 Functional principle

The pumps of this series are external gear pumps, which operate according to the displacement principle.



S Suction connection
P Pressure connection

During rotation, two interlocking gears cause a volume increase by opening the tooth spaces on the suction side (S), so that the medium can flow in and at the same time, on the discharge side (pressure side, P), a corresponding volume is displaced by the meshing of the teeth in the filled tooth gaps. Fluid transport takes place through entrainment in the tooth spaces along the wall of the wheel chamber.

With each gear rotation, the so-called geometric displacement volume V_g is displaced.


A value that is named the rated volume V_{gn} in technical documents to specify the pump size.

The displacement process described takes place initially without a noticeable pressure build-up. Only after external loads are applied, e.g. by head, flow resistances, pipe elements, etc., does the required working pressure set in to overcome these resistances.

The pressure applied to the shaft seal equals the pressure at the suction connection of the product. The permissible pressure is determined by the type of seal.


3.2 Variants

Gear pump




- | | | | |
|----|--------------------|----|---------------------------------|
| 1 | End cover | 2 | Seal |
| 3 | Housing | 4 | Plain bearings |
| 5 | Driven shaft | 6 | Gears |
| 7 | O-ring | 8 | Flange cover |
| 9 | Roller bearings | 10 | O-ring |
| 11 | Seal retainer | 12 | Shaft seal |
| | | | (Types of seals [► 17]) |
| 13 | End of drive shaft | 14 | Valve |
| | | | (only Direction of rotation: 3) |

Gear pump with pressure relief valve




- 1 Pressure relief valve
- 2 Gear pump
- 3 Collar nut
- 4 Cover
- 5 Adjustment screw


Valve cover



Thread protective cap




Cap nut



Cap nut KN17

Gear pump with Universal valve



- 1 Universal valve
- 2 Gear pump
- 3 Piston

3.3 Type key

Ordering example																		
KF		3/	63		F	1	0	B		P	0	0		7	D	P	2	/197
1.		2.	3.		4.	5.	6.	7.		8.	9.	10.		11.	12.	13.	14.	15.

Ordering example			
+		DKF 3	D
		16.	17.
+		KF 4 U 04	
		19.	

Explanation of type key

1. Product name

2. Size

3	4	5	6
----------	----------	----------	----------

3. Nominal

V_{gn}	KF 3/. : 63; 80; 100; 112
	KF 4/. : 125; 150; 180
	KF 5/. : 200; 250; 315
	KF 6/. : 400; 500; 630; 730

4. Fixing type

F	KF 3/. A-Ø= 180; Z-Ø= 130; LK-Ø= 150	H	KF 5/. – KF 6/. A-Ø= 250; Z-Ø= 180; LK-Ø= 215
G	KF 4/. A-Ø= 220; Z-Ø= 150; LK-Ø= 185		

A= Outer diameter; Z= Centering diameter; LK=Bolt circle

5. Direction of rotation

1	Clockwise	3	Clockwise/counterclockwise with changing direction of delivery
2	Counterclockwise		

6. Outboard flange

X	Mounting angle	0	Without
----------	----------------	----------	---------

7. Construction of housing

B	Housing with flange connection
----------	--------------------------------

8. Shaft end

P	Cylindrical shaft end Without Roller bearings	M	Cylindrical shaft end with roller bearings (reinforced)
N	Cylindrical shaft end with roller bearings	R	Cylindrical shaft end with roller bearings (reinforced) Shaft end shortened

9. 2nd shaft end

0	Without
----------	---------

Explanation of type key			
10. End cover			
A	Only for direction of rotation 1 or 2	0	Without end cover (For valve installation)
B	Only for Direction of rotation 3		
11. Design serial number (specified by manufacturer)			
12. Housing material and plain bearing			
D	EN-GJL-250 Multi layer friction bearings (contains lead)	V	EN-GJS-400-15 Multi layer friction bearings (contains lead)
13. Gears version			
P	Helical gear		
14. Seal type			
1	Rotary shaft seal NBR	74	Mechanical seal with CR secondary seals Q3ANFE (KF 3/.) (For compressor applications)
2	Rotary shaft seal FKM	75	Mechanical seal with HNBR secondary seals Q3AVFE (KF 3/.) (For compressor applications)
29	Mechanical seal with FKM secondary seals SAVGG	77	Mechanical seal with FKM secondary seals Q3AVFE (KF 3/.) (For compressor applications)
30	Mechanical seal with PTFE secondary seals SATGG	79	Rotary shaft seal FKM (Low temperature) (only applies to KF 4/.)
32	Rotary shaft seal PTFE	87	Mechanical seal with CR secondary seals (AX20) Q2B2K1G3 (KF 4/. – KF 6/.) (For compressor applications)
37	Rotary shaft seal FKM (Low temperature) (only applies to KF 3/.)	88	Mechanical seal with HNBR secondary seals (AX20) Q2B2K1G3 (KF 4/. – KF 6/.) (For compressor applications)
39	Mechanical seal with FKM secondary seals SAVGG (with fluid buffer)	89	Mechanical seal with FKM secondary seals (AX20) Q2B2K1G3 (KF 4/. – KF 6/.) (For compressor applications)
40	Mechanical seal with PTFE secondary seals QQTGG (with fluid buffer)		


Explanation of type key			
15. Special number			
Special numbers [▶ 20]			
16. Pressure relief valve			
DKF 3	For KF 3/.	DKF 5	For KF 5/.
DKF 4	For KF 4/.	DKF 6	For KF 6/.
17. Pressure relief valve			
A	Housing material: EN-GJL-250	L	Housing material: EN-GJS-400-15
	Pump side seal:		Pump side seal:
	Other seals O-ring NBR		Other seals O-ring FKM
	Cover: Thread protective cap		Cover: Cap nut
C	Housing material: EN-GJL-250	N	Housing material: EN-GJS-400-15
	Pump side seal:		Pump side seal:
	Other seals O-ring Cu		Other seals O-ring Cu
	Cover: Cap nut KN 17		Cover: Cap nut KN 17
D	Housing material: EN-GJL-250	U	Housing material: EN-GJL-250
	Pump side seal:		O-ring: Material defined by pump
	Other seals O-ring FKM		Cover: Thread protective cap
	Cover: Thread protective cap		
G	Housing material: EN-GJS-400-15	V	Housing material: EN-GJS-400-15
	Pump side seal:		O-ring: Material defined by pump
	Other seals O-ring NBR		Cover: Cap nut
	Cover: Cap nut		

Explanation of type key			
H	Housing material: EN-GJL-250	W	Housing material: EN-GJL-250
	Pump side seal: Other seals O-ring NBR		O-ring: Material defined by pump
	Cover: Cap nut		Cover: Cap nut
K	Housing material: EN-GJL-250		
	Pump side seal: Other seals O-ring FKM		
	Cover: Cap nut		
18. Pressure setting ranges			
04	2 – 4 bar	16	8 – 16 bar
08	4 – 8 bar	25	16 – 25 bar
19. Universal valve			
KF 4 U 04	For KF 3/.	KF 5 U 07	For KF 5/250 – KF 5/315
KF 4 U 05	For KF 4/.	KF 6 U 08	For KF 6/.
KF 5 U 06	For KF 5/200		

3.4 Direction of rotation and discharge

The direction of rotation is indicated by the curved arrow, when looking towards the end of the drive shaft. The pump connections are below the drive shaft.


The flow direction is indicated by the straight arrow.



S = Suction connection

P = Pressure connection

3.5 Types of seals




Rotary shaft seal

Shaft end: P; U

Seal type: 1; 2; 32; 37; 79

Special number: 155; 197; 250; 291; 304; 317; 332; 344; 353; 370; 398; 454; 472




Rotary shaft seal with roller bearings

Shaft end: K; M; N; R

Seal type: 1; 2; 32

Special number: 18; 20; 24; 45; 51; 61; 70; 79; 89; 104; 122; 149; 196; 197; 221; 222; 260; 265; 266; 304; 326; 336; 352; 378; 397; 398; 427




Rotary shaft seal (for vacuum operation)


Shaft end: P

Seal type: 1; 2


Special number: 191




Double rotary shaft seal
 Connecting pipe 8x1 (for fluid buffer)
 Shaft end: P
 Seal type: 1; 2; 32
 Special number: 44; 261; 297; 306; 440




Double rotary shaft seal (for vacuum operation)
 Connecting pipe 8x1 (for fluid buffer)
 Shaft end: P
 Seal type: 1; 2
 Special number: 74; 309




Triple rotary shaft seal
 (for vacuum operation / for normal operation)
 Connecting pipe 8x1 (for fluid buffer)
 Shaft end: P
 Seal type: 1; 2
 Special number: 94




Double rotary shaft seal
 with grease filling
 Shaft end: P
 Seal type: 1; 2
 Special number: 255




Mechanical seal
with roller bearings
Shaft end: N
Seal type: 29; 30; 87; 88; 89
Special number: 304; 317; 332;445; 446; 447;
531



Mechanical seal
Connection borehole G 1/4 (for fluid buffer)
Shaft end: N
Seal type: 39; 40



Mechanical seal
Shaft end: N
Seal type: 43; 55; 56;74; 75; 77
Special number: 153; 172; 177; 216; 379; 393;
415; 438




Without shaft seal

Shaft end: N; R

Seal type: 1; 2

Special number: 95; 104; 196; 296; 308; 369



Without shaft seal

without roller bearings

Shaft end: P

Seal type: 1; 2

Special number: 104; 196; 266; 301; 498

3.6 Fluid seal

Versions with a fluid seal are used if absolute leak tightness is required at the shaft seal, e.g. when pumping media

- which harden on contact with air.
- which crystallise on contact with the moisture in air.
- which must not be allowed to leak into the environment.
- which are under vacuum and whose seal should be gas tight.

Select the installation so that the connection for the fluid seal is at the top.


3.7 Special numbers

Special number	Description
18	Strengthened shaft execution (M-Shaft)
20	Strengthened shaft execution (M-Shaft)
24	6-hole mounting flange
44	Double rotary shaft seal
45	Cylindrical shaft end - with centring hole DIN 332-2 Type D
51	Cylindrical shaft end - with centring hole DIN 332-2 Type D
61	Tapered shaft end

Special number	Description
70	Pipe adaptor ; 2nd shaft end Customized type plate
74	Double rotary shaft seal for vacuum operation
79	Shaft end bored through End cover with Connection M22x1,5
89	Flange cover with sidwise recess
94	Triple rotary shaft seal
95	Without shaft seal Lubricating oil bore in flange cover
104	Without shaft seal
122	Special number 79 End cover with G ½ Connection
149	2nd shaft end
153	For compressor applications O-ring: CR Plastic plain bearings (non-ferrous metal-free)
155	Shaft end with splined shaft profile Leak oil drain through nozzle in end of drive shaft
172	For compressor applications O-ring: HNBR Plastic plain bearings (non-ferrous metal-free)
177	For compressor applications Special number 153 End cover als Suction connection with adapter plate
191	Rotary shaft seal for vacuum operation + Special number 197
196	Without shaft seal + Special number 197
197	Noise-optimized version for oils containing air
216	For compressor applications Special number 177 O-ring HNBR
221	Combination of Special number 122 + 197
222	Combination of Special number 79 + 197
250	Combination of Special number 155 + 197
255	Use under water Double rotary shaft seal BABSL + grease fill Fastening screws: stainless steel (A4) + Special number 197

Special number	Description
260	with Universal valve Noise-optimized version
261	Combination of Special number 44 + 197
265	Use under water Special number 260 Sealing faces are additional seal
266	Without shaft seal Leak oil drain through nozzle in end of drive shaft + Special number 197
291	Stainless steel type plate and rivets
296	with Universal valve Without shaft seal Noise-optimized version
297	Inner rotary shaft seal, Turcon Roto Variseal (p _{max} = 10 bar at 700 1/min) Outer rotary shaft seal, BABSL Plastic plain bearings (non-ferrous metal-free) Hennecke type plate
301	Combination of Special number 196 + 282
304	Plastic plain bearings (non-ferrous metal-free)
306	Plastic plain bearings (non-ferrous metal-free) Hennecke type plate + Special number 197
309	Combination of Special number 74+197
317	Combination of Special number 197 + 304
326	Combination of Special number 45 + 197 KF 150 + KF 200: shaft end hole M8 / 19 mm deep
332	Special number 304
336	Without shaft seal with roller bearings
344	Gear pump horizontal, shaft end below the connections + Special number 197
352	with Universal valve O-ring FKM Low temperature + Special number 197
353	Multi layer friction bearings (non-ferrous metal-free) + Special number 197
369	Combination of Special number 45 + 196

Special number	Description
370	Shaft end with splined shaft profile With SAE B 2-hole flange Plastic plain bearings (non-ferrous metal-free)
378	O-ring sealing at flange cover centring
379	For compressor applications O-ring: CR Plastic plain bearings (non-ferrous metal-free)
393	For compressor applications Special number 153 O-ring: FKM
397	Use under water With universal valve Fastening screws: stainless steel
398	Use under water Fastening screws: stainless steel + Special number 197
415	For compressor applications Special number 379 O-ring: HNBR
427	Special number 197 Special shaft end
438	For compressor applications Special number 379 O-ring: FKM
440	Special number 44 Rotary shaft seal BABSL
445	For compressor applications Optimierte Dichtungsschmierung Plastic plain bearings (non-ferrous metal-free)
446	For compressor applications Special number 445
447	For compressor applications Special number 445
454	Shaft end with nozzle + Special number 197
472	Combination of Special number 44 + 197 Plastic plain bearings (non-ferrous metal-free)
498	Special number 266
531	White metal bearing + Special number 197



Size	with	Special number	L	S _{h6}	M	d _{k6}	d1	l	m	n	t	u
KF 3	Mechanical seal	-	120	130	5	24	35	50	30	10	27	8
		153/172/177/ 216/379/415	60			19	19	40		5	21.5	6
KF 4		-	125	150	8	24	25	50	40	5	27	8
		445/446/447/ 531	110			19	20	40	30		21.5	6
KF 5		-	125	180		28	30	60	10	31	8	
		447	120			24	25	50	40	5		27
KF 6	-	160	38			40	80	63	8	41	10	
	153/172/447	125	32			35	50	40	5	35		

4 Technical data

4.1 General

General information				
Housing connection	KF 3/.		Flange connection	SAE 1 1/2" – M10
	KF 4/.			SAE 2"
	KF 5/200			SAE 2 1/2"
	KF 5/250 – KF 5/315			SAE 3" – M12
	KF 6/.			SAE 4"
	KF 3/. + KF 4 U 04			SAE 2"
	KF 4/. + KF 5 U 07			
	KF 5/200 + KF 5 U 06			
	KF 5/315 + KF 5 U 07			SAE 3" – M12
	KF 6/. + KF 6 U 08	Suction connection		SAE 4"
Pressure connection		SAE 3" – M12		
Mounting position	KF without fluid buffer		Any	
	KF with fluid buffer		Shaft end horizontal , fluid buffer connection top	
	KF with Universal valve		Piston horizontal , Pressure connection on top	
Mounting position For compressor applications	Special number	153; 172; 177; 216; 393; 446	Vertical, shaft end up	
		379; 415; 438; 445; 531	Shaft end horizontal	
		447	Shaft end horizontal / Vertical, shaft end up	
External loads on shaft end	KF		Axial and radial forces are only permissible in combination with an outboard bearing	
	KF with Mechanical seal		Axial and radial forces are not allowed	
Speed	n	Nominal sizes [▶ 27] + Assignment of viscosity - speed [▶ 28]		
Operating pressure	p_e	Allowable pressures [▶ 28]		
	p_b			
Viscosity	v_{min}	Assignment of viscosity - speed [▶ 28]		
	v_{max}	15000 mm ² /s		
Fluid temperature	ϑ_m	Permissible temperature range [▶ 32]		
Ambient temperature	ϑ_u			
Filtering	β	≤ 60 μm		

General information	
Materials	Material data [▶ 33]
Permissible media	Lubricating fluids without abrasive components (Petrols, solvents, etc. are not permissible) For compressor applications : Refrigeration oil (max. 5% gas content), Hydraulic oil; Mineral oil



TIP

A reduced shaft seal life is possible in the vertical installation position (shaft end at the top).

4.2 Nominal sizes

Nominal	Geom. displacement	Speed		Perm. radial force	Perm. axial force	Sound pressure level	Mass inertia
		n_{min}	$n_{max}^{(2)}$				
V_{gn}	V_g	[rpm]		F_{radial} [N]		$L_{pA}^{(1)}$	$\times 10^{-4}$
	[cm ³ /rev.]			(n = 1500 rpm)		[dBA]	J (kg m ²)
KF 3/63	63.8	200	2000	1500	200	≤ 75	4.25
KF 3/80	81.3					≤ 76	5
KF 3/100	100.8					≤ 77	6.75
KF 3/112	112.6					≤ 78	7.5
KF 4/125	129					≤ 79	13.75
KF 4/150	153					≤ 80	16
KF 4/180	184					≤ 81	19.25
KF 5/200	204			2000	300	≤ 82	27.5
KF 5/250	255					≤ 83	34.5
KF 5/315	321					≤ 84	43
KF 6/400	405			1500	500	≤ 85	105
KF 6/500	505					≤ 83	130
KF 6/630	629					≤ 84	160
KF 6/730	730					≤ 85	195

⁽¹⁾ n = 1500 rpm; v = 34 mm²/s; p = 5-25 bar
⁽²⁾ Pay attention to the viscosity

4.3 Assignment of viscosity - speed

Kinematic viscosity ν [mm ² /s]	Recommended rpm n [rpm]
400	2000
500	1800
1000	1200
2000	800
3000	650
6000	450
10000	300
15000	250
20000	200



TIP

Select the speed of rotation so that complete filling of the pump is ensured. This is the case if the pressure on the suction side does not fall below the permissible pressure $p_{e \text{ min}}$.

4.4 Allowable pressures

4.4.1 Operating pressure at suction side

Seal type	Special number	Operating pressure	
		Suction side	
		$p_{e \text{ min}}$ [bar _{abs.}]	$p_{e \text{ max}}$ [bar _{rel.}]
1	-	0,6 ⁽¹⁾	1 (KF 5/: 0,5)
	74	0,1	0,2
	191		
	196	0,6 ⁽¹⁾	Operating pressure at pressure side ▶ 30]
	309	0,1	0,2
2	-	0,6 ⁽¹⁾	1 (KF 5/: 0,5)
	74	0,1	0,2
	191		
	196	0,6 ⁽¹⁾	Operating pressure at pressure side ▶ 30]
	309	0,1	0,2
29	-	0,6 ⁽¹⁾	10
30	-		
32	-		
37	-		0,5

Seal type	Special number	Operating pressure	
		Suction side	
		$p_{e \text{ min}}$ [bar _{abs.}]	$p_{e \text{ max}}$ [bar _{rel.}]
39	-		10
40	-		
79	-		0,5

bar_{abs.} = Absolute pressure; **bar_{rel.}** = Relative pressure
⁽¹⁾ Start-up condition: 0.4 bar absolute (max. 30 minutes)

with Universal valve		
Nominal V_{gn}	Operating pressure	
	Suction side	
	$p_{e \text{ min}}$ [bar _{abs.}]	$p_{e \text{ max}}$ [bar _{rel.}]
KF 3/63	0.64	Operating pressure at suction side [▶ 28]
KF 3/80		
KF 3/100		
KF 3/112	0.65	
KF 4/125	0.66	
KF 4/150	0.67	
KF 4/180	0.68	
KF 5/200	0.62	
KF 5/250	0.63	
KF 5/315	0.64	
KF 6/400	0.63	
KF 6/500	0.64	
KF 6/30	0.67	
KF 6/730	-	

bar_{abs.} = Absolute pressure; **bar_{rel.}** = Relative pressure

4.4.2 Operating pressure at pressure side

Nominal V_{gn}	Operating pressure	
	Pressure side	
	p_b [bar] (perm. continuous pressure)	$p_{b\ max}$ [bar] (Maximum pressure) ⁽¹⁾
KF 3/63	25	50
KF 3/80		40
KF 3/100		30
KF 3/112		25
KF 4/125		40
KF 4/150		30
KF 4/180		25
KF 5/200		30
KF 5/250	20	25
KF 5/315	16	20
KF 6/400	25	30
KF 6/500	20	25
KF 6/630	16	20
KF 6/730	14	16

⁽¹⁾ Maximum pressure: only applicable when using mineral oil at speeds of >700 1/min and viscosity values of 30 mm²/s – 1000 mm²/s

4.4.3 Compressor application

Seal type	Special number	Operating pressure		
		Suction side		Pressure side
		$p_{e\ min}$ [bar _{abs.}]	$p_{e\ max}$ [bar _{rel.}]	p_b [bar] (perm. continuous pressure)
74	153	0,6 ⁽¹⁾	25	35 KF 6/730: 31
	177			
	379			
75	172			
	216			
	415			
77	393			
	438			
87	445			
	446			
	447			
88	445			
	446			
	447			

Seal type	Special number	Operating pressure		
		Suction side		Pressure side
		$p_{e\ min}$ [bar _{abs.}]	$p_{e\ max}$ [bar _{rel.}]	p_b [bar] (perm. continuous pressure)
89	445			
	446			
	447			

bar_{abs.} = Absolute pressure; **bar_{rel.}** = Relative pressure
⁽¹⁾ Start-up condition: 0.4 bar absolute (max. 30 minutes)

4.5 Assignment of differential pressure to viscosity

Plain bearings	Δp_{max} [bar]		
	$v = 1,4\ mm^2/s$	$v = 6\ mm^2/s$	$v = 12\ mm^2/s$
Multi layer friction bearings (contains lead) (Standard)	3	12	KF 3/.
			KF 4/.
			KF 5/200
			KF 5/250
			KF 5/315
Multi layer friction bearings (non-ferrous metal-free)			KF 6/400
			KF 6/500
			KF 6/630
			KF 6/730
Plastic plain bearings	-	3	10 ⁽¹⁾
White metal bearing			KF 6/730: 6 ⁽¹⁾

⁽¹⁾ For compressor applications $v \geq 7\ mm^2/s$

4.6 Permissible temperature range

Sealing material	Fluid temperature ϑ_m	
	$\vartheta_{m \min}$ [°C]	$\vartheta_{m \max}$ [°C]
CR	-20	100
EPDM		120
FEP with FKM-core		200
FFKM / FEP with FKM-core		200
FKM		150
HNBR		90
NBR		200
PTFE / FEP with FKM-core		200
FKM (Low temperature)		-30

Sealing material	Ambient temperature ϑ_u	
	$\vartheta_{u \min}$ [°C]	$\vartheta_{u \max}$ [°C]
CR	-20	60
EPDM		
FEP with FKM-core		
FFKM / FEP with FKM-core		
FKM		
HNBR		
NBR		
PTFE / FEP with FKM-core		
FKM (Low temperature)		



NOTICE

Note media-specific properties.



NOTICE

Size 3 gear pumps for compressor application have bearing material Iglidur® G, here is the fluid temperature $\vartheta_{m \max}$ 110 °C.

4.7 Material data

Seal type	Materials				
	Shaft seal	O-ring / Gas- ket	Housing / Flange cover / End cover / Valve housing	Gears	Plain bearings
1	NBR	NBR, C4400	EN-GJL-250 --- EN-GJS-400-15	Casehardened steel 16MnCrS5 - 1.7139	Multi layer fric- tion bearings (contains lead) (Steel (St), CuSn, PTFE, Pb) --- Plastic plain bearings non- ferrous metal- free Iglidur® ---
2	FKM	FKM, C4400			
29	SAVGG, FKM, 1.4571	FEP, C4400			
30	SATGG, PTFE, 1.4571				
32	PTFE				
37	FKM (Low temperature)				
39	SAVGG, FKM, 1.4571	FKM, C4400			Multi layer fric- tion bearings (non-ferrous metal-free) (Steel (St), CuSn, PTFE) --- White metal bearing (Steel (St), SnS- b12Cu5Cd or SnSb12Cu6
40	QQTGG, PTFE, 1.4571	FEP with FKM- core, C4400			
79	FKM (Low temper- ature)	FKM (Low temper- ature)			

4.7.1 Compressor application

Seal type	Materials				
	Shaft seal	O-ring / Gas-ket	Housing / Flange cover / End cover / Valve housing	Gears	Plain bearings
74	Q3ANFE, CR	CR	EN-GJL-250 - - - EN-GJS-400-15	Casehardened steel 16MnCrS5 - 1.7139	Plastic plain bearings non- ferrous metal- free Iglidur® X Iglidur® G Iglidur® H370
75	Q3AP1FE, HNBR	HNBR			
77	Q3AVFE, FKM	FKM			
87	Q2B2K1G3, FFKM	CR			
88	Q2B2K1G3, FFKM	HNBR			
89	Q2B2K1G3, FFKM	FKM			

Refrigerant		Oil							
		M	M*	M*-PAO	AB	E	PAO	AB-PAO	PAG
R717 (NH3)	Ammonia	CR / HNBR	CR / HNBR	CR / HNBR	CR	-	CR ⁽¹⁾ / HNBR	CR	CR / HNBR
R290 (C3H8)	Propane	-	-	-	-	-	HNBR	-	HNBR
R1270 (C3H6)	Propylene	-	-	-	-	-	HNBR	-	HNBR
R744 (CO2)	Carbon dioxide	-	-	-	-	CR	HNBR	-	HNBR
R22	H-CFC	CR	-	-	CR	CR	-	CR	-
R134a, R404a, R407C, R410A, R507, R23	H-FC	-	-	-	-	HNBR	-	-	-

⁽¹⁾ only for oils: Fuchs Reniso Synth 68, Klüber Summit R100/R150/R200

M= Mineral oil

M*= Mineral oil with special treatment (hydrocracked oil)

AB= Alkylbenzene

E= Polyester

PAO= Polyalphaolefin

PAG= Polyalkylglykol

4.8 Weight

Nominal V_{gn}	Gear pump with [kg]			Added weight [kg]	
	End cover	Pressure relief valve	Universal valve	Mechanical seal	Mounting angle
KF 3/63	12	13,5	32	1,5	2,6
KF 3/80					
KF 3/100	13,5	15	34		
KF 3/112					
KF 4/125	18,5	20	39		4,9
KF 4/150	20	21,5	40		
KF 4/180	21	22,5	41		
KF 5/200	28	30	80	2	8,8
KF 5/250	33	35	85		
KF 5/315					
KF 6/400	51	59	103	3	18,8
KF 6/500	55	63	107		
KF 6/630	65	73	117		
KF 6/730					

4.9 Dimensions

The dimensions of the product are given in the technical data sheets.

5 Transport and storage

5.1 General

- a) After receiving the delivery, check the product for transport damage.
- b) If transport damage is found, the manufacturer and the transport company must be notified immediately. The product must then be replaced or repaired.
- c) Dispose of packaging materials and used parts according to local regulations.

5.2 Transport



⚠ WARNING

Falling or toppling loads

Risk of injury during transport of large and heavy loads.

- a) Use only suitable means of transport and lifting gear with sufficient load-bearing capacity.
- b) Attach lifting gear only to suitable places on the load.
- c) Attach the lifting gear so that it cannot slip.
- d) Note the centre of gravity of the load.
- e) Avoid sudden, jerky movements, impacts and strong vibrations during transport.
- f) Do not step under overhead loads, do not work under overhead loads.



NOTICE

Eyebolts can be screwed into the thread of the flanged connections to transport the product.

5.3 Storage

The product's function is tested in the factory with mineral hydraulic oil. The connections are then closed. The remaining residual oil preserves the internal parts for up to 6 months.

Bright metallic external parts are also protected against corrosion by suitable preservation measures for up to 6 months.

During storage, ensure a dry, dust-free and low-vibration environment. The product must be protected from weather, moisture and large temperature fluctuations. Comply with the recommended storage conditions.

Below the permissible ambient temperature ϑ_U , elastomer seals lose their elasticity and mechanical loading capacity, as the temperature is below the glass transition temperature. This process is reversible. Avoid the application of force on the product during storage below the permissible ambient temperature ϑ_U .

Products with EPDM seals are not mineral oil resistant and their function is not tested. The internal parts are not preserved. If the product is not put into operation immediately, all surfaces exposed to corrosion must be protected by suitable preservation measures. The same applies to products that are not tested for other reasons.

In case of storage for a longer period (> 6 months), all surfaces exposed to corrosion must be retreated with suitable preservatives.

If high humidity or an aggressive atmosphere is to be expected, additional suitable corrosion prevention measures must be taken.



NOTICE

Storage in corrosion protection bags (VCI) for maximum 6 months.

⚠ ATTENTION

Corrosion/chemical attack

Improper storage can make the product unusable.

- a) Use suitable preservation measures to protect exposed surfaces.
- b) Comply with the recommended storage conditions.

5.4 Storage conditions



TIP

Recommended storage conditions

- a) Storage temperature: 5 °C – 25 °C
- b) Relative humidity: < 70 %
- c) Protect elastomer parts from light, particularly direct sunlight.
- d) Protect elastomer parts from oxygen and ozone.
- e) Note the maximum storage period of elastomer parts:
 - ⇒ 5 years: AU (polyurethane rubber)
 - ⇒ 7 years: NBR, HNBR, CR
 - ⇒ 10 years: EPM, EPDM, FEP/PFTE, FEPM, FKM, FFKM, VMQ, FVMQ

6 Installation

6.1 Safety instructions for installation



DANGER

Hazardous fluids

Danger to life when handling hazardous fluids

- a) Comply with the safety data sheets and regulations on handling the hazardous fluids.
- b) Collect and dispose of hazardous fluids so that no hazard is created for persons or the environment.



DANGER

Rotating parts

Risk to life due to entanglement or winding of parts of the body, hair or clothing items.

- a) Before carrying out any work, disconnect any drives and actuators from the power supply or depressurise them.
- b) Safely prevent restarting during the work.



DANGER

Rotating parts

Risk to life due to entanglement or winding of parts of the body, hair or clothing items.

- a) Take measures to prevent accidental touching of rotating parts.



WARNING

Rotating parts

Risk of injury caused by ejected parts

- a) Enclose rotating parts so that in the event of fracture or malfunction, there is no risk caused by ejected parts.



WARNING

Exposed gears

Gearwheels can trap and crush fingers and hands.

- a) Do not engage gearwheels.

**⚠ WARNING****Failure of pressure bearing parts due to overload**

Risk of injury from flying parts.

Risk of injury due to splashing fluids.

- a) Before carrying out any work, depressurise the product and all connection pipes.
- b) Securely prevent the pressure from being restored during work.

**⚠ WARNING****Failure of pressure bearing parts due to overload**

Risk of injury from flying parts.

Risk of injury due to splashing fluids.

- a) Use only connections and lines approved for the expected pressure range.
- b) Securely prevent the permissible pressures from being exceeded, e.g. by using pressure relief valves or bursting discs.
- c) Pipelines must be designed in such a way that no tension e.g. caused by changes in length due to fluctuations in temperature can be transferred to the product.

6.2 Noise reduction

**TIP****Measures to reduce noise**

- a) Use of suction and pressure hoses.
- b) Use of pump supports with high damping properties (plastic or grey cast iron)
- c) Use of damping rings and damping rails to isolate structure-borne sound.

6.3 Mechanical installation

6.3.1 Preparation

-
- a) Check the product for transport damage and contamination.
 - b) Check the product for smooth and easy movement.
 - c) Remove any preservative present.
 - d) Clean all lines.
 - ⇒ Only use cleaning agents that are compatible with the materials used.
 - ⇒ Do not use cleaning wool.
 - e) Compare the environmental and ambient conditions at the place of use with the permissible conditions.
 - ⇒ Make sure that the foundation is sufficiently stable and level.
 - ⇒ Expose the product only to low vibrations, see IEC 60034-14.
 - ⇒ Ensure sufficient accessibility for maintenance and repair.
 - f) Position the product and secure it against slipping.
 - ⇒ Comply with the manufacturer's instructions.
 - ⇒ Do not use any sealing materials such as hemp, Teflon tape or putty.
 - g) Remove existing protective plugs.
-

6.3.2 Gear pump with free shaft end

Suitable power transmission between the gear pump and drive is required for fault-free operation.

In a standard product, a flexible claw coupling is used for this.

-
- a) Preassemble the coupling parts as described by the manufacturer.
 - b) Position the pump and drive relative to each other.
 - ⇒ Note the allowable installed position.
 - ⇒ Note the allowable direction of rotation.
 - c) Tighten the fastening screws to the specified torque.
-



⚠ DANGER

Rotating parts

Risk to life due to entanglement or winding of parts of the body, hair or clothing items.

- a) Take measures to prevent accidental touching of rotating parts.
-



⚠ CAUTION

Hot surfaces

Burns of the skin on contact.

- a) Wear protective gloves at temperatures $\geq 48^{\circ}\text{C}$.

Tightening torques [Nm]							
Thread size	M6	M8	M10	M12	M16	M20	M24
Counter-thread Aluminium	4.6	11	22	39	95	184	315
Counter-thread Cast iron / Steel	10	25	49	85	210	425	730

Screws/Nuts with min. strength class 8.8/8



NOTICE

- a) Comply with the allowable displacement values of the coupling.
- b) Prevent stressing of the product.
- c) Make sure the fastening screws have sufficient depth of engagement.



NOTICE

- a) In case of products without a shaft seal, make sure that the leaked oil from the shaft seal space is removed in a controlled way and does not get into the environment.
- b) Make sure that foreign objects cannot get into the product.
- c) If products have a fluid seal, install a tank for holding the seal fluid.
 - ⇒ Install the tank above the product.
 - ⇒ The connection on the device must face upwards.
 - ⇒ It must be possible to check the fluid level at any time.

6.4 Connection lines

6.4.1 General



WARNING

Failure of pressure bearing parts due to overload

Risk of injury from flying parts.

Risk of injury due to splashing fluids.

- a) Use only connections and lines approved for the expected pressure range.
- b) Securely prevent the permissible pressures from being exceeded, e.g. by using pressure relief valves or bursting discs.
- c) Pipelines must be designed in such a way that no tension e.g. caused by changes in length due to fluctuations in temperature can be transferred to the product.



NOTICE

Additional connections

- a) Provide measurement connections for pressure and temperature as near as possible on the device.
- b) If necessary, provide an option for filling and draining the device and line system.
- c) If necessary, provide an option for venting the device and line system.

6.4.2 Suction line

A suction line that is not optimally designed can lead to increased noise emissions, cavitation and even a reduction in the capacity (due to less filling of the pump).


When designing the lines, bear in mind the following points:

- Lay the suction line as short and straight as possible.
- Specify the nominal size of the suction line so that the operating pressure on the suction side is not less than the permissible operating pressure $p_{e \text{ min}}$.
- Avoid large suction heights.
- Avoid additional pressure loss through line resistances such as fittings, screwed connections, formed parts or suction filters/suction baskets. Ensure that all technically required suction filters/suction baskets are appropriately dimensioned.
- Pay attention to sufficient distance of the suction opening from the floor and walls of the media tank.
- Make sure that the suction opening is below the lowest fluid level in any operating situation.
- When using hoses, make sure that they have sufficient stability so that they do not become constricted by the suction effect.
- Note the recommended flow velocity in the suction line (max. 1.5 m/s).

Suction line at vacuum operation

If medium is to be drawn from a tank under vacuum, the pump must be positioned approx. 1 m below the tank. The suction line must be laid straight and without any resistances.

The tank may be subjected to vacuum only then when the pipework and the pump have been filled with liquid. Only pumps suitable for vacuum operation may be used for this purpose.



NOTICE


Cavitation damage

Pressure below the permissible suction side pressure causes cavitation


- a) Design the suction line so that the pressure that sets in during operation is always higher on the suction side than the vapour pressure of the pumped medium. At the same time, make sure that the device is installed above sea level.
- b) If fluids contain water, install the device below the fluid level and limit the operating temperature to 50 °C and the speed to 1500 1/min.

Prevention of suction problems


If there is a possibility of the suction line running dry while the pump is at a standstill, laying the suction line as a U-trap is a way of avoiding suction problems. This way, the pump will remain permanently filled after initial commissioning.



In case of longer suction lines that can run empty during the standstill, it is useful to insert a foot valve or a non-return valve. These must have been designed for use in suction lines and should offer as low a flow resistance as possible.



When operating a pump that has to pump via a non-return valve into a pressurized circuit (e.g. reserve pump in a lubricant circuit), intake difficulties can occur if the suction line is filled with air. In this case the pressure line must be vented directly upstream of the non-return valve. If a venting nozzle is not inserted, the volume of the pressure line between the pump and non-return valve must be at least 75% of the suction line volume.



6.4.3 Pressure pipe

When designing the lines, bear in mind the following points:

- Choose the nominal size of the pressure line so that the maximum permissible pressures are not exceeded.
- If necessary, provide a venting nozzle to prevent suction problems.

6.4.4 Connection line installation

- a) Clean all lines.
 - ⇒ Do not use cleaning wool.
 - ⇒ Pickle and rinse welded pipes.
- b) Remove existing protective plugs.
- c) Install the lines.
 - ⇒ Comply with the manufacturer's instructions.
 - ⇒ Do not use any sealing materials such as hemp, Teflon tape or putty.



TIP

Location of the device connections: **Direction of rotation and discharge** [▶ 16]

6.5 Change of the direction of rotation

Depending on the design, a change in direction of rotation is possible.

The modification required is normally carried out by the manufacturer and should only be carried out by the customer in exceptional cases. Please consult the manufacturer for this purpose.



NOTICE



For gear pumps with special number, check whether the direction can be reverted.



NOTICE

The gear pump type KF 6/370 does not allow for the rotation direction to be reversed. Unit must be replaced.

6.5.1 Gear pump without noise optimisation



S = Suction connection
 P = Pressure connection

1 Fastening screws
 2 Leak oil hole
 3 Adjustment screw

To change the direction of rotation of the gear pump, turn the end cover or the pressure relief valve 180°.

- a) Undo the fastening screws.
- b) Remove the end cover or the pressure relief valve respectively from the pump housing and put it back on rotated by 180°.
- c) Tighten the fastening screws with the stated torque.

Zahnradpumpe	Tightening torques [Nm] fastening screws end cover
KF 3	25
KF 4	
KF 5	49
KF 6	




NOTICE

When checking, pay attention to the following points:

- a) Gear pumps without pressure relief valve must have the leak oil hole in the end cover on the inlet side.
- b) Gear pumps with pressure relief valve must have their pressure relief valve adjusting screw point toward the pump's suction side.

6.5.2 Gear pump with noise optimisation



- S = Suction connection
- P = Pressure connection
- 1 Fastening screws
- 2 Leak oil hole
- 3 Adjustment screw

To change the direction of rotation of the gear pump, turn the end cover or the pressure relief valve 180°.

- a) Undo the fastening screws.
- b) Remove the end cover or the pressure relief valve respectively from the pump housing and put it back on rotated by 180°.
- c) Tighten the fastening screws with the stated torque.

Gear pump	Tightening torques [Nm] fastening screws flange cover
KF 3	49
KF 4	
KF 5	
KF 6	85



NOTICE

When checking, pay attention to the following points:

- a) The notches in the wheel chamber in housing must be located on the delivery side of the pump.
- b) Gear pumps without pressure relief valve must have the leak oil hole in the end cover on the inlet side.
- c) Gear pumps with pressure relief valve must have their pressure relief valve adjusting screw point toward the pump's suction side.

7 Commissioning

7.1 Safety instructions for start-up



⚠ DANGER

Hazardous fluids

Danger to life when handling hazardous fluids

- a) Comply with the safety data sheets and regulations on handling the hazardous fluids.
- b) Collect and dispose of hazardous fluids so that no hazard is created for persons or the environment.



⚠ WARNING

Failure of pressure bearing parts due to overload

Risk of injury caused by flying parts.

Risk of injury caused by splashing fluids.

- a) Do not operate the product with shut-off devices closed.
- b) Do not operate the production in the wrong rotational direction.



⚠ CAUTION

Hot surfaces


Burns of the skin on contact.

- a) Wear protective gloves at temperatures $\geq 48^{\circ}\text{C}$.

7.2 Preparation

- a) Before starting the system make sure that a sufficient quantity of the service fluid is extant to avoid dry running. This must be taken into account especially with large line volumes.
- b) Check all fastening screws on the product.
- c) Fill the pump and the suction line with medium.

7.3 Filling the quench chamber



- 1 Quench chamber
2 Container for quench-liquid

- a) For versions with fluid seal, fill the quench chamber with a suitable seal fluid.
 ⇒ Fill from the tank provided.
 ⇒ Fill fluid until the quench chamber is completely full and the tank is half full.
- b) Do not apply pressure or vacuum to the quench chamber.



NOTICE


Seal failure due to running dry

Lack of seal fluid can cause the seal to fail.

- a) Do not start up the pump without seal fluid.

7.4 Pressure valve setting

The valves are set to the rated pressure of the respective pressure stage in the factory. Set pressures deviating from this are given on the type plate.



- | | | | |
|---|--------------------------|---|------------------|
| - | response pressure lower | 1 | Cover |
| + | response pressure higher | 2 | Collar nut |
| | | 3 | Adjustment screw |

- a) Remove cover.
- b) Loosen the hexagon nut.
- c) Use the adjusting screw to set the set pressure.
- d) Secure the adjusting screw with a hexagon nut.
- e) Mount cover.



⚠ WARNING

Failure of pressure bearing parts due to overload

Risk of injury from flying parts.

Risk of injury caused by splashing fluids.

- a) Note the permissible pressure setting range of the valve.
- b) Check the pressure setting (the valve must not block).

7.4.1 Pressure relief valve

Directly attached series D pressure relief valves are used only to protect the gear pump and may only operate for a short time.



NOTICE

Failure of the gear pump

Longer operation of the valve can cause the gear pump to overheat.

- a) Operate the valve for a short time only.

7.5 Additional commissioning

- a) Open existing shut-off elements in front of and behind the product.
 - b) Set pressure relief valves installed in the system to the lowest opening pressure.
 - c) Start the product without pressure load or with low pressure (jog mode).
 - ⇒ A flow should have developed after 30 s at the latest.
 - d) Run the product pressureless or at low pressure for a few minutes.
 - e) Vent the system at the highest possible point.
 - f) Gradually increase the pressure up to the required operating pressure.
 - g) Operate the system until the final operating condition is reached.
 - h) Check the operating data.
 - ⇒ **Maintenance table [▶ 55]**
 - i) Document the operating data of the initial commissioning for later comparison.
 - j) Check the level of the operating medium in the system.
 - k) Check the level of the seal fluid (if present).
 - l) Check the product for leaks.
 - m) Check all fittings for leaks and retighten if necessary.
-

8 Removal

8.1 Safety instructions for disassembly



⚠ DANGER

Hazardous fluids

Danger to life when handling hazardous fluids

- a) Comply with the safety data sheets and regulations on handling the hazardous fluids.
- b) Collect and dispose of hazardous fluids so that no hazard is created for persons or the environment.



⚠ DANGER

Rotating parts

Risk to life due to entanglement or winding of parts of the body, hair or clothing items.

- a) Before carrying out any work, disconnect any drives and actuators from the power supply or depressurise them.
- b) Safely prevent restarting during the work.



⚠ WARNING

Exposed gears

Gearwheels can trap and crush fingers and hands.

- a) Do not engage gearwheels.



⚠ WARNING

Failure of pressure bearing parts due to overload

Risk of injury from flying parts.

Risk of injury due to splashing fluids.

- a) Before carrying out any work, depressurise the product and all connection pipes.
- b) Securely prevent the pressure from being restored during work.



⚠ CAUTION

Hot surfaces

Burns of the skin on contact.

- a) At temperatures ≥ 48 °C, allow the product to cool first.

 **ATTENTION****Blocking of the product due to curing media**

Curing media can mechanically block the product and make it unusable.

- a) Clean the product immediately after operation with curing media.

8.2 Dismantling

- a) Depressurise and de-energise the system.
- b) Close existing shut-off elements in front of and behind the product.
- c) Open existing drain elements and undo connection lines. Collect and dispose of leaking media so that no hazard is created for persons or the environment.
- d) Dismantle the product.
- e) Clean the product.
- f) Seal the process connections and lines to prevent the ingress of dirt.

**NOTICE**

The concrete procedure for cleaning depends on the media being used.

- a) See the safety data sheet of the media in use.

9 Maintenance

9.1 Safety instructions for maintenance



⚠ DANGER

Hazardous fluids

Danger to life when handling hazardous fluids

- a) Comply with the safety data sheets and regulations on handling the hazardous fluids.
- b) Collect and dispose of hazardous fluids so that no hazard is created for persons or the environment.



⚠ DANGER

Rotating parts

Risk to life due to entanglement or winding of parts of the body, hair or clothing items.

- a) Before carrying out any work, disconnect any drives and actuators from the power supply or depressurise them.
- b) Safely prevent restarting during the work.



⚠ WARNING

Failure of pressure bearing parts due to overload

Risk of injury from flying parts.

Risk of injury due to splashing fluids.

- a) Before carrying out any work, depressurise the product and all connection pipes.
- b) Securely prevent the pressure from being restored during work.



⚠ CAUTION

Hot surfaces

Burns of the skin on contact.

- a) At temperatures ≥ 48 °C, allow the product to cool first.

9.2 Maintenance work



TIP

Checking and documentation of the operating data

Regular checking and documentation of all operating data helps to detect faults at an early stage.

- Perform the maintenance work according to specifications.
- Replace defective or worn components.
- If necessary, request spare parts lists and assembly drawings from the manufacturer.
- Document the type and scope of the maintenance work along with the operating data.
- Compare the operating data with the values of the initial commissioning.
In case of large deviations (> 10 %), determine the cause.
- Dispose of packaging materials and used parts according to local regulations.



NOTICE

Protective devices and notes

After maintenance and/or repair, reattach all protective devices and notices removed in the process to their original position.

9.3 Maintenance instructions

The following information provides recommendations for maintenance work and maintenance intervals for the product in use.

Depending on the actual loads occurring during operation, the type, scope and interval of the maintenance work may deviate from the recommendations. A mandatory maintenance plan must be drawn up by the installer/operating company.



TIP

In the course of preventive maintenance, it is advisable to replace wearing parts before the wear limit is reached.

With the appropriate know-how and sufficient equipment, the repair can also be carried out by the installer/operating company.

If necessary, request spare parts lists and assembly drawings from the manufacturer.

Please consult the manufacturer for this purpose.



NOTICE

Warranty

Any warranty will be void if not executed properly.

9.4 Maintenance table

9.4.1 Maintenance table

		Firstly:after max. 24 h	Daily	3000 Operating hours	6000 Operating hours	As required	Additional information
9.4.2	Check the rate of flow	2					
9.4.3	Check the operating pressure	2					
9.4.4	Check the media temperature	2					
9.4.5	Check the device temperature	2					
9.4.6	Check the function of the add-on valve	2					
9.4.7	Check the equipotential bonding	2					
9.4.8	Check the condition of the operating fluid	2					
9.4.9	Auditory check Unusual noises		1				
9.4.10	Cleaning		1				
9.4.11	Visual inspection for leakage		1				
9.4.12	Visual check of seal fluid level		2				
9.4.2	Check the rate of flow			2			
9.4.3	Check the operating pressure			2			
9.4.4	Check the media temperature			2			
9.4.5	Check the device temperature			2			
9.4.6	Check the function of the add-on valve			2			
9.4.7	Check the equipotential bonding			2			
9.4.8	Check the condition of the operating fluid			2			
9.4.13	Visual check of the gearbox condition				3		
9.4.14	Visual check of the condition of housing parts				3		
9.4.15	Visual check of the condition of the plain bearings				3		
9.4.16	Visual check of the condition shaft seal				3		
9.4.17	Visual check of the condition of the out-board bearing				3		
9.4.18	Replacing the outboard bearing					3	
9.4.19	Replacing the plain bearings					3	
9.4.20	Replacing the shaft seal					3	
9.4.21	Replacing other seals					3	

1 - 0,1 h; 2 - 0,2 h; 3 - 0,75 h

9.4.2 Check the rate of flow

The rate of flow is measured via the volumetric flow meter.

The values are displayed by the built-in controller in the electrical control system.

- If there is no discharge flow, check the individual components of the product.
- Comply with the product-specific data sheets/operating instructions.

9.4.3 Check the operating pressure

The operating pressure is indicated by the pressure gauges.

- If there is no operating pressure, check the individual components of the product.
- Comply with the product-specific data sheets/operating instructions.

9.4.4 Check the media temperature

The media temperature is measured through the temperature sensor.

The values are displayed by the built-in controller in the electrical control system.

- If the media temperature is too high or too low, check the product components.
- Comply with the product-specific data sheets/operating instructions.

9.4.5 Check the device temperature

Measure the surface temperature in the area of the bearing.

9.4.6 Check the function of the add-on valve

Add-on valves must be operated at regular intervals. This is necessary to ensure their faultless function.

9.4.7 Check the equipotential bonding

Check the equipotential bonding for tight fit and proper functioning.

9.4.8 Check the condition of the operating fluid

Pay attention to colour (dark colouring), odour and milky turbidity.

- Replace operating fluid if necessary.

9.4.9 Auditory check Unusual noises

In this case, attention must be paid to increased noise or uneven operation (pump unit).

- In case of unusual noises, examine the individual components of the product and line fixings and check the operating medium for foaming.
- Comply with the product-specific data sheets/operating instructions.

9.4.10 Cleaning

Remove dust deposits and dirt with a damp, clean cloth.

9.4.11 Visual inspection for leakage

Care must be taken here to ensure that there is no leakage from the connections.

- In the event of leaks in the connections, the glands must be tightened and, if necessary, the seals replaced.

9.4.12 Visual check of seal fluid level

Pay attention to the level of the seal fluid. If necessary, top up the seal fluid.

If there is no automatic monitoring, the filling level must be checked at least before each shift begins.

If the level drops unusually quickly within a short time, it is possible that the outer or inner shaft seal is leaking.

If the level increases, it is likely that the inner shaft seal is leaking and barrier medium is mixed with the pumped medium.

- Stop plant operation immediately in both cases.

9.4.13 Visual check of the gearbox condition

The driving shaft pinion and driven shaft pinion are wearing parts. In case of excessive wear, the parts or the pump must be replaced.

Important places to check are the surfaces opposite the shaft seal and bearing bushes, end faces of the driving shaft pinion and driven shaft pinion as well as the tooth flanks.

9.4.14 Visual check of the condition of housing parts

Important places to check are the end faces of the impeller chamber.

9.4.15 Visual check of the condition of the plain bearings

The plain bearings are wearing parts. In case of excessive wear, the parts or the pump must be replaced.

In case of multilayer plain bearings, the wear limit is reached if the bronze layer of the bearing is 50-70 % exposed.

When loaded on the suction side, the driving shaft pinion and driven shaft pinion are supported in the bearings so that wear is identified there first.

9.4.16 Visual check of the condition shaft seal

Pay attention to leak quantities and impermissible temperature increases.

- Small leaked quantities are indispensable for the function of the seal.
- In case of excessive leaked quantities or impermissible temperature increase, the pump must be shut down immediately. Replace the seal.

9.4.17 Visual check of the condition of the outboard bearing

The outboard bearing is a wearing part.

The life of the bearing primarily depends on the operating conditions.

The bearing should therefore be checked for damage after 4000 h at the latest. In the event of unacceptable wear, the bearing must be replaced.

Onsetting wear or pending failure can become noticeable due to increased heating of the bearing, increased power consumption, irregular running or even noise emissions.

9.4.18 Replacing the outboard bearing

With the appropriate know-how and adequate equipment, the repair can also be carried out by the installer/operating company.

To this end, if necessary, request spare parts and assembly drawings from the manufacturer.

Only use spare parts approved by the manufacturer.

9.4.19 Replacing the plain bearings

These are replaced only by the manufacturer.

Contact the manufacturer.

9.4.20 Replacing the shaft seal

With the appropriate know-how and adequate equipment, the repair can also be carried out by the installer/operating company.

To this end, if necessary, request spare parts and assembly drawings from the manufacturer.

Only use spare parts approved by the manufacturer.

9.4.21 Replacing other seals

With the appropriate know-how and adequate equipment, the repair can also be carried out by the installer/operating company.

To this end, if necessary, request spare parts and assembly drawings from the manufacturer.

Only use spare parts approved by the manufacturer.

10 Repair

10.1 Safety instructions for repairs



DANGER

Hazardous fluids

Danger to life when handling hazardous fluids

- a) Comply with the safety data sheets and regulations on handling the hazardous fluids.
- b) Collect and dispose of hazardous fluids so that no hazard is created for persons or the environment.



DANGER

Rotating parts

Risk to life due to entanglement or winding of parts of the body, hair or clothing items.

- a) Before carrying out any work, disconnect any drives and actuators from the power supply or depressurise them.
- b) Safely prevent restarting during the work.



WARNING

Failure of pressure bearing parts due to overload

Risk of injury from flying parts.

Risk of injury due to splashing fluids.

- a) Before carrying out any work, depressurise the product and all connection pipes.
- b) Securely prevent the pressure from being restored during work.



CAUTION

Hot surfaces

Burns of the skin on contact.

- a) At temperatures ≥ 48 °C, allow the product to cool first.

10.2 General

Corrective maintenance includes:

1. Troubleshooting
Finding damage, determining and localising the cause of the damage.
2. Damage repair
Removing the primary causes and replacing or repairing defective components. Repairs are generally carried out by the manufacturer.

Repair by the manufacturer

Before returning the product, fill out the return form. The form can be filled out online and is available to download as a pdf file or can be requested from the manufacturer.



NOTICE

Device contains hazardous substances

If the device has been operated with hazardous fluids it must be cleaned before it is returned. If this is not possible, the safety data sheet of the hazardous material must be provided in advance.

Repair by the installer/operating company

With the appropriate know-how and sufficient equipment, the repair can also be carried out by the installer/operating company. Please consult the manufacturer for this purpose.

- a) If necessary, request spare parts lists and assembly drawings from the manufacturer.
- b) Only use spare parts approved by the manufacturer.
- c) Dispose of packaging materials and used parts according to local regulations.



NOTICE

Warranty

Any warranty will be void if not executed properly.



NOTICE

Protective devices and notes

After maintenance and/or repair, reattach all protective devices and notices removed in the process to their original position.

10.3 Fault table

Fault	Potential causes	Possible measures
Increased noise		
Pump cavitation	Excessive negative pressure (not complete filling of the pump)	Check suction line design Use noise-optimised pump
	Suction line clogged	Clean the suction line
	Suction filter plugged or too small	Clean suction filter or use a larger filter
		Replace filter element
	Suction basket plugged or too small	Clean intake strainer or dimension larger
	Fluid temperature too low	Adjust the temperature of medium
Foaming or air in media	Pump does not suck	Check the oil level in the tank
		Check suction line
		Check the shaft seal
	Shaft seal defective	Replace seals
	Suction connection leaking	Tighten or replace the screw connections
		Replace seals
	System not vented	Vent the system
Return line ends above the fluid level	Extend return line	
Heavy foaming in the system, e.g. in gears	Use noise-optimised pump	
Mechanical vibrations	Incorrectly aligned and/or loose coupling	Correct the alignment of the coupling and secure the coupling halves
	Incorrectly and/or insufficient line fastening	Fixate lines with suitable fastening material (e.g. pipe clamps)
	Wobbling pressure relief valve	Increase valve opening pressure
	Not a noise-reducing setup	Use dampers
Pump does not suck		
	Dry run	Fill pump and the suction line with medium
	Minimum filling level in the reservoir tank undercut	Refill media
	Wrong direction of rotation	Correct the direction of rotation
	Throttled/closed shut-off element in the suction line	Open the shut-off element
	Suction line clogged	Clean the suction line

Pump does not suck		
	The air in the suction line cannot be compressed in the pressure line	Reduce the start-up pressure
		Vent the pressure line
		Increase volume of the pressure line
	Speed of the pump is too low	Check the pump design
		During frequency inverter operation: Check the operation/line frequency
	Geodetic suction head too high	Check installation location
Provide pre-filling pump		
Insufficient pressure		
Insufficient pumping flow rate		
	Excessive negative pressure (not complete filling of the pump)	Check suction line design
	Too high media viscosity	Provide pre-filling pump
	Speed of the pump is too low	Check the pump design
		During frequency inverter operation: Check the operation/line frequency
	Throttled/closed shut-off element in the suction line	Open the shut-off element
	Suction line clogged	Clean the suction line
	Suction filter plugged or too small	Clean suction filter or use a larger filter
		Replace filter element
	Suction basket plugged or too small	Clean intake strainer or dimension larger
	Constant triggering of pressure relief valve (if existing)	Increase valve opening pressure
	Pump does not suck	Check the oil level in the tank
		Check suction line
Check the shaft seal		
Wear	Replace the device	
Excessive operating temperature		
	Cooling and heat dissipation insufficient	Increase the cooling capacity
	Not sufficient oil in the system	Check the container layout
	Excess fluid is being delivered into the supply tank via pressure relief valve under load	Check the pump design

Impermissible pump heating		
	Constant triggering of pressure relief valve (if existing)	Increase valve opening pressure
	Pressure too high in association with a media viscosity that is too low	Check the system design
	Speed too fast in connection with media viscosity that is too high	Check the system design
	Gland lid overtightened (for gland seal)	Unscrew gland lid and readjust leakage
	Suction pressure too high	Reduce the pressure
	Wear	Replace the device
Leakage		
Seal failure	Lack of maintenance	Comply with maintenance inter-vals
		Replace seals
	Mechanical damage	Replace seals
	Thermal overload	Check operating data
		Replace seals
	Pressure too high	Check operating data
		Replace seals
	Gas content in media too high	Check operating data
		Replace seals
	Corrosion/chemical degradation	Check material compatibility
Replace seals		
Wrong direction of rotation	Correct the direction of rotation	
	Replace seals	
Contaminated medium	Provide filtration	
	Replace seals	
Gland lid not sufficiently tightened (for gland seal)	Retighten gland lid	
Loose screw connection	Tighten or replace the screw connections	
Coupling		
Coupling wear	Alignment error	Correct the alignment of the coupling and secure the coupling halves
	Spider overloaded	Check operating data
		Use harder spider
Cam break	Spider wear Torque transmission due to metal contact	Adapt maintenance intervals
		Replace coupling

Premature spider wear	Alignment error	Correct the alignment of the coupling and secure the coupling halves
		Replace spider
	Spider failure due to chemical corrosion	Check material compatibility
		Replace spider
Motor protection switch tripped		
	Driving power too low	Check the drive design
	Motor incorrectly connected	Check motor connection
	Phase failure	Check feed/supply
	Current consumption too high	Check operating data
		Check direction of rotation
Motor circuit breaker incorrectly designed	Check operating data	
Consult the manufacturer in the event of unidentifiable faults		